


PF4A: 'Snap' frames podium stands on two aluminium posts

| COMPONENT LIST | A1L | A2L |
|---|-------------|-------------|
| Angled aluminium post, either angled at 15 degrees or fitted with angled plate (45 or 60 degrees) | 2 | 2 |
| Weighted oval base (8mm mild steel, powder-coated) | 800x400mm | 600x300mm |
| Spigot (to fix post to base) | 2 | 2 |
| 'Snap' frame on strengthening aluminium strip | A1, 6 holes | A2, 6 holes |
| Stainless steel bolt (to fix 'snap' frame to posts) | 4 | 4 |

ASSEMBLY INSTRUCTIONS

FIX BASES TO POSTS

- 1. Undo spigot (remove bolt)
- 2. Put bolt through weighted base plate from underside
- 3. Part-screw rectangular fitting (comes split diagonally into two parts) back on to bolt
- 4. Place rectangular part of fitting inside base of upright (opposite end to angled plate)
- 5. Tighten bolt using large allen key supplied (to lock base securely into upright).




PF4A: 'Snap' frames podium stands on two aluminium posts

FIX SNAP FRAME TO POSTS

FIX 'SNAP' FRAME TO POSTS (15 degree angle)

- 1. Unscrew the snap frame from the aluminium strip (2x M5x10 machine screws screwed
 - through from underside of aluminium strip into central position on left and right edges of snap frame)
- 2. Remove the two protruding screws (M6x16) from the tops of the aluminium posts
- 3. Attach the aluminium strip to the posts re-using the M6x16 machine screws
- 4. Re-attach the snap frame to the aluminium strip using the M5x10 screws



FIX 'SNAP' FRAME TO POSTS (45 or 60 degree angle)

- 1. Unscrew the snap frame from the aluminium strip (2x M5x10 machine screws screwed through from underside of aluminium strip into central position on left and right edges of snap frame)
- 2. Remove the two protruding screws (M6x16) from the angled plate at the top of each aluminium post
- 3. Attach the aluminium strip to the plate(s) re-using the M6x16 machine screws
- 4. Re-attach the snap frame to the aluminium strip using the M5x10 screws

